

Cable #	Description
1	Input: Phase power for receiver
2	Input: Neutral power for receiver
4	Output: Mainline
5	Input: Power for hoist/trolley
9	Output: Hoist up
10	Output: Hoist down
11	Output: Hoist high speed
12	Output: Horn
14	Output: Trolley left
13	Output: Trolley right
15	Output: Trolley high speed
3	Input: Power for bridge
7	Output: Bridge forward
6	Output: Bridge reverse
8	Output: Bridge high speed

**WRST-24012302v01**  
Operating Mode 1

